

510-537 INSTALLATION INSTRUCTIONS 2003-04 Toyota Tundra 4.7L 2004 Toyota 4Runner 4.7L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

Thank you for selecting AIRAID.



INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE AIRAID.COM FOR CARB STATUS ON EACH PART FOR A SPECFIC VEHICLE.

Included with your Poweraid Spacer is a sticker with a California Air Resources Board (C.A.R.B.) Executive Order (EO) number. This sticker must be placed in plain view inside of the engine compartment. Failure to do so may prevent you from passing a smog inspection.

Parts List		
AIR-KIT537PA	Aluminum Plate	(1)
AIR-KIT537H	Hardware	
"O" - Rings		(3)
8mm x 100mm Hex Bolts		(4)
8mm Flat Washers		(4)

Tools List

10mm Socket

Installation Instructions. Read Me!

1. <u>DISCONNECT NEGATIVE (-) BATTERY CABLE</u>.

- 2. Remove air intake hose assembly.
- **3.** Remove throttle body cover and save nuts.
- **4.** Remove throttle body bolts, nuts, and studs.
- 5. Remove throttle body and install power plate using (3) "O" Rings, (4) 8mm x 100mm hex bolts, and
 - (4) 8mm flat washers. (**Ref. "A", "B")**
- 6. Inspect & Test throttle linkage for full Open & Closed travel before driving. Some cruise or kickdown cables may require adjustment.

 Please refer to your vehicles service manual for proper adjustment.
- 7. Reinstall throttle body cover using saved nuts and air intake hose. (Ref. to Steps 2 & 3)
- **8.** Reconnect negative battery cable. Enjoy!

The sound of power...The "whistle" means its working!

Ref. "A"- (1) Power Plate (3) "O"-Rings



Ref. "B"- (4) 8mm x 100mm Hex Bolts (4) 8mm Flat Washers

AIR-I51537B Rev. 01.03.17