



# INSTALLATION INSTRUCTIONS

## Part Number YA-4098-1DK

This Drycharger fits: YA-4098-1DK

The K&N Drycharger is a specially designed filter wrap made to extend the service interval of your K&N Filtercharger® when used in very dirty, muddy or dusty conditions. They are made from a highly durable silicone treated polyester material containing uniform micron openings. The Drycharger will stop small dirt particles with minimal restriction to the airflow of the filter. The Drycharger is designed to be run dry and can be cleaned with K&N Filter Cleaner or soap and water. The Drycharger is custom made to fit each application.

### INSTALLATION

1. Sand the surrounding surface of the XStream Top® where the Velcro will be placed. (Fig. 1)  
**Note:** It is recommended that you use 120 grit sand paper.  
**CAUTION:** Do not allow sand paper to touch the surface of the pleated material.
2. Once the surface of the XStream Top® has been sanded, apply a small amount of acetone, paint thinner or rubbing alcohol on a rag and clean the sanded areas to remove any dust or oil that may be on the XStream Top®.  
**CAUTION:** Do not allow the cleaning agent to touch the surface of the pleated material.
3. Apply enough of the provided Super Glue to the XStream Top® for one piece of Velcro. (Fig. 2)
4. Remove the backing from the Velcro and apply to the XStream Top®. (Fig. 3)  
**Note:** The glue on the Velcro will take 24 hours to completely set.
5. Repeat these two steps for the two other Velcro pieces. (Fig. 4)
6. Install the Drycharger onto the XStream Top® making sure the Drycharger is properly aligned. (Fig. 5)  
**Note:** The hole in the Drycharger lines up with the hole in the XStream Top®.
7. Install the Drycharger onto the base of the K&N Filtercharger®.  
**Note:** The Drycharger logo will line up with the air filter locator. (Fig. 6)  
**Note:** The elastic of the Drycharger will fit on the molded material of the K&N Filtercharger®. Make sure the Drycharger does not slip onto the sealing surface of the base of the K&N Filtercharger® otherwise the air filter will not seal correctly in the air box. (Fig. 7)
8. When installing the K&N Filtercharger® into the air box follow the instructions for the air filter. When the XStream Top® is installed the washers and the wing bolt will go on top of the Drycharger.

**Note:** If the edges of the Velcro start to peel off of the XStream Top®, you can repair it by applying a small amount of Super Glue to the XStream Top®.




Fig. 1



Fig. 2




Fig. 3




Fig. 4




Fig. 5



Fig. 6



Fig. 7